



Solar Power Pedestal Instructions

1. Separate the battery box from the Carson box by unscrewing the eye bolt located on the left side of the battery.
2. Make sure the Carson box orientation aligns with the solar panel facing due south (check Carson box for indication on which side of the box needs to face south).
3. Bury the green Carson Box so that the top is level with the ground. (Make sure it is facing south)
4. Feed load wires from Carson through the hole on the left side of the battery box.
5. Replace battery box on top of Carson box and put eye bolt back in position.
6. Connect the load wires to the labelled wires inside battery box.
7. Turn the battery switch on so that the battery diagram is horizontal.
8. Connect the Solar panel fuse positive cable. (Make sure this is done after you turn on the battery switch)
9. Read controller instructions for load preferences.
10. Fan toggle switch can be used if installed in warm environments.
11. Call Dan Hammond for questions (760) 408-0353.